AUTODOC CLUB

How to change fuel filter on **VW Scirocco III Box Body / Hatchback (137)** – replacement guide

SIMILAR VIDEO TUTORIAL

VW
TOURAN I (1T1, 1T2)

This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:
VW Scirocco III Box Body / Hatchback (137) 2.0 TDi

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: VW Touran I (1T1, 1T2) 2.0 TDI

REPLACEMENT: FUEL FILTER – VW SCIROCCO III BOX BODY / HATCHBACK (137). TOOLS YOU MIGHT NEED:

- All-purpose cleaning spray
- Torx bit T20
- Fluid container
- Round-nose pliers
- Flat Screwdriver
- Torque wrench
- Crow bar
- Fender cover

Buy tools

Replacement: fuel filter – VW Scirocco III Box Body / Hatchback (137).
AUTODOC recommends:

- Ensure adequate ventilation of the workplace. Fuel vapors are poisonous.
- All work should be done with the engine stopped.

REPLACEMENT: FUEL FILTER – VW SCIROCCO III BOX BODY / HATCHBACK (137). USE THE FOLLOWING PROCEDURE:

1 Open the bonnet.

2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

3 Clean the fuel filter housing and the cover. Use all-purpose cleaning spray.

4 Unscrew the fasteners of the fuel filter housing cover. Use Torx T20.

5 Remove the fuel filter housing cover. Use a crowbar.

6 Prepare a container for fluids.

7 Remove the fuel filter. Use round-nose pliers.

8 Put the old filter cartridge in the container.

Replacement: fuel filter – VW Scirocco III Box Body / Hatchback (137). AUTODOC experts recommend:

- Be careful! Fuel may leak from the filter housing and hoses.

9 Remove the old sealing ring. Use a flat screwdriver.

10 Install the new sealing ring. Use a flat screwdriver.

11 Install a new fuel filter.

Replacement: fuel filter – VW Scirocco III Box Body / Hatchback (137). Tip from AUTODOC:

- Make sure that the fuel filter is positioned correctly. Consider the fuel flow direction mark.
- During installation, take care to prevent dust and dirt from getting into the fuel filter housing.
- Take care to only use quality filters.

12 Install and tighten the cap of the fuel filter housing.

13 Tighten the fasteners of the fuel filter housing cover. Use Torx T20. Use a torque wrench. Tighten it to 8 Nm torque.

Replacement: fuel filter – VW Scirocco III Box Body / Hatchback (137). Tip:

- Before starting off, switch the ignition on and off several times. This should be done to activate the fuel pump to make it pump fuel through the fuel system.

14 Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

15 Shut off the engine.

16 Remove the fender protection cover.

17 Close the hood.

Replacement: fuel filter – VW Scirocco III Box Body / Hatchback (137). Professionals recommend:

- To protect the environment from pollution, be sure to dispose of the used filters at special collection points.

WELL DONE!

VIEW MORE TUTORIALS

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.